

SPECIAL INSTRUCTIONS

C.N.X. Models

There are 3 sets of 'A' poles and a longer ridge pole on these models.

Extension

This uses an extra 'A' frame plus a short 120cm ridge pole which fits over the pin of the front 'A' pole of the main tent. (Available for Mk 4 and Mk 5 tents). The canopy of this extension can be raised by using two 150cm canopy extension poles (available extra). This canopy can be opened on either side of the tent. The extension does not have an inner or groundsheet.

Flysheet first

It is possible, with practice, to erect tent flysheet first which is particularly useful in bad weather.

Tent Care

Never store the tent wet, particularly a cotton tent.

It is possible to re-proof the fabric of your tent. For advice consult your specialist retailer.

On the nylon flysheet it may be advisable to seal the stitching holes which may become enlarged through use or in cold weather. Vango seam sealant is recommended for this purpose.

Take special care when erecting the tent as the 'A' piece is particularly prone to damage through misuse. Pegs should be inserted at approximately a 45 degree angle. Lastly, do not use the peg lugs of the groundsheet to pull out pegs from the ground.

A full range of spares and accessories is available through Force Ten stockists.



VANGO (SCOTLAND) LTD.

70 EAST HAMILTON STREET, LADYBURN, GREENOCK PA15 2UB