

SUNBEAM 450 LIGHT SYSTEM

OPERATING INSTRUCTIONS

READ ALL INSTRUCTIONS CAREFULLY BEFORE USE
KEEP THESE INSTRUCTIONS FOR REFERENCE



CE MADE IN CHINA

CARRY BAG CONTAINS


- ① LED Light Bar x 4
- ② 2.4m Extension x 2
- ③ 5m Extension x 2
- ④ On/Off Switch x 4
- ⑤ UK Plug with EU Adaptor x 1
- ⑥ 10cm Loop/Hook Strap x 10
- ⑦ 45cm Loop/Hook Strap x 10
- ⑧ 3-Way Splitter x 1
- ⑨ Remote Control x 1
- ⑩ Waterproof Caps x 4
- ⑪ Car Adaptor x 1

**IMPORTANT: CHECK THE CONTENTS OF YOUR SYSTEM TO ENSURE ALL COMPONENTS
HAVE BEEN SUPPLIED**

OPERATING INSTRUCTIONS

Set up:

Requires: UK/EU plug or car adaptor, remote control sensor cable, extension cable (if required), on/off switch, LED light bar/s.



A

UK/EU plug or car adaptor



remote control sensor cable

B


remote control sensor cable



extension cable

C

Extension cables (2.4m or 5m) can be used if required between lights bars or between remote control sensor cable and on/off switch.



on/off switch

D

On/off switches can be fitted and screwed between each light bar, to allow them to be switched on or off independently:



on/off switch

light bar

Waterproof caps supplied, to be screwed onto the end of light bar fitting:




The 3-way splitter is designed to allow lights to be set up on different circuits:

Note: An on/off switch should be fitted and screwed to each separate circuit.



Use loop/look straps to secure light bar to desired beam, pole or surface:



Using the remote control:

This remote control is not weatherproof and must have adequate protection from moisture and rain.

Turn on the light. Brightness can be adjusted to 25%, 50% or 100% by using (+) or (-) buttons.

The mode button will cycle through the lighting effects including 'Strobe'.

Care should be taken when using 'Strobe' lighting.

To personalise your remote control to your Sunbeam Light System
Press and Hold Speed + and Speed - for 3 seconds



TROUBLESHOOTING

The LED Light is not illuminating when I switch it on using the On/Off Switch.

(1) Check all connections are secure. Check power supply is plugged in and switched on.

Note: Some car sockets can be a loose fit and cause problems with the connection.

(2) If it is still not working try unplugging the On/Off Switch and connect the LED directly to the power source.

What happens if an individual LED gets damaged? Will the entire LED stop working?

No. The LED will continue working except for the damaged LED chip. Note: The LED's are arranged in lots of three. Therefore if one is damaged, the other two will continue to work.

Can the LED's be repaired if damaged?

No, once they are damaged they remain like this.

The remote dimmer control appears to stop working or is working intermittently.

Check all connections are secure and the power source is plugged in and turned on. If it is still not working check/replace the batteries in the hand remote by removing the back cover.

When using the 3-Way Splitter, do I need to use leads on all connections?

No. You can either run 1, 2 or 3 additional circuits of the splitter.

How many Light Bars can I use at the same time?

A maximum of 6 x LED light bars can be used of one circuit. Any additional bars may cause overheating and damage to the circuits.

WARNING

- Some items in the kit are for indoor use only and should have adequate weather protection.
- Do not look directly at LED lights as it can cause eye damage.
- Read all instructions before use. If you are unsure on any items, please direct your questions to the place of purchase.

VANGO WARRANTY POLICY:

All Vango products are designed and manufactured to exacting standards and are covered by our user warranty.

The warranty covers all manufacturing faults of the fabrics, parts and workmanship. This warranty* covers the functionality of the product for its normal, intended use as specified in the consumer literature or website. It does not cover a malfunction that has resulted from improper or unreasonable use or maintenance, accidents, damage due to excessive winds/weather, improper re-packing or natural degradation due to sunlight.

The Vango Warranty lasts TWO YEARS from the date of purchase as standard**.

Consumers who register their products on the Vango website will receive an extended warranty on the registered product-

- The Vango two year warranty will be extended to three years**.

*For full details please see appropriate section on Vango website at www.vango.co.uk

**This may vary depending on the statutes in force within the country of purchase.

IF YOU ENCOUNTER ANY PROBLEMS PLEASE CONTACT YOUR LOCAL RETAILER or
AMG Group Ltd., Kelburn Business Park, Port Glasgow, Scotland, PA14 6TD

UK Consumer Hotline: 0844 811 0535 Email: info@vango.co.uk

Calls to our Customer Hotline cost 5p per minute. Calls from mobile phones, cable networks or public payphones will generally cost more.

Vango makes every effort to ensure the accuracy of the information shown within this document, however we do pursue a policy of continuous improvement and we therefore reserve the right to change or amend information and specifications without prior notice.